

Local Mode Download & Upload

On the controller navigate to the following

1. Setup/Run>Configure>Network
2. Select and Disable DHCP
3. Setup/Run>Configure>Network>Settings
4. Select and assign IP Address 192.168.0.1
5. Select and assign Subnet/IP Mask 255.255.255.0
6. Setup/Run>Configure>Network
7. Press Reset (Option Zero) on the keypad

On your laptop (Windows)

1. Disable Wifi
2. Click Start
3. Navigate to Control Panel
4. Select Network Connections
5. Right click on Local Area Connection
6. Left click on Properties
7. Ensure TCP/IP V6 is disabled or unchecked
8. Select TCP/IP V4 and click properties
9. Select Use the following IP Address
10. Assign IP 192.168.0.2
11. Assign Subnet Mask 255.255.255.0
12. Click Ok and or Apply
13. Close out the open windows

Connecting and retrieving the data

1. Ensure your laptop is plugged directly to your controller with a Crossover cable (won't work with a standard cat5)
2. Open Internet Explorer
3. Type in the address bar exactly 192.168.0.1 (no www or http)
4. Press enter and key in login credentials (factory default is admin / 0000)
5. Click logs on the top left
6. Select WebAdvantage Upload Format to download (may take several minutes to complete)
7. Save the file to your computer where you can locate it later

Uploading data to WebAdvantage

If the controller has never been connected to the server please email Chris.Liebig@advantagecontrols.com the exact model number and serial number of the controller before attempting to upload to server.

1. Login to the web server (enhanced)
2. Locate the controller you have data for and click Reports
3. Click history upload on the left
4. Click Choose File and select the file you saved to your computer
5. Click submit and the data will upload
6. You will now be able to view reports and history data once completed.